Wholehouse Fan Cover



Always Clase Both Surfaces Selve Attaching Advancer Strips

Gean surface of shutter and cover material Clear surface of structure and control
thoroughly before attaching adhesive backed fastener.



Hook and loop come mated together.



Trim to length as necessary.

Real off bathing from loop side (not fuzzy title) and attach along perimeter of shorter approximately is inch from the edge. Firmly sub-trip to shorter to get a good bond. Do for all four

Peel off remaining backing.





Attach the insulated cover (silver side towards shutter) to the hook side (rough prickly side) leaving an overhang on all four sides.

5. Firmly rub to get a good bond.



Trim excess cover material 7. using fastener as a border.





8. Atrach finished cover.

